


TRAFFIC CALMING DEVICES





SPEED CUSHION DESIGN



- Raised area on a roadway that does not cover the entire width of the road
- Designed to accommodate wide wheel base of emergency vehicles (easy passage)
- Designed to discourage drivers from travelling at excessive speeds
- A series of speed cushions is more effective than a single installation
- Use on neighbourhood roads



FLEXIBLE BOLLARDS








Angel Pass Drive

- Existing bollard
- Proposed bollard



Proposed Speed cushion

